
## ASSEMBLY INSTRUCTIONS



## **PARTS LIST**

(ASSEMBLY PARTS)

	(ASSEMBL)	PARIS)	
#1	#2	#3	#4
Table Body 1 set	Leg 2 pieces	Score Board 1 set	Wood Holder 1 piece
#5	#6	#7	#8
Pebble 1 piece	Wax 1 piece	Wooden Brush 1 piece	Eraser 1 piece
#9	#10	#11	#12
	6	66666	5 <u>6</u> 55
Pen 1 piece	Handle 1 piece	Stones Colour #1 8 pieces	Stones Colour #2 8 pieces
#13	#14	#15	#16
			0
Leg Leveler 4 pieces	Allen Tool 1 piece	M8X45MM Bolt 8 pieces	19MM Washer 8 pieces
#17	#18	#19	#20
		Ourmin	Omm C
4x32mm Screw 4 pieces	Plastic Anchor 4 pieces	4x32mm Bolt 1 piece	Door Handle 2 sets
#21	#22	#23	#24
			9 <sub>9</sub> 9
Soft Cover 1 piece	Score 1 piece	Box 1 piece	Puck Colour #2 4 pieces
#25	#26	#27	#28
© © ©			
Puck Colour #1 4 pieces	Adapter 1 piece	3-pc Top Board 1 set	Wooden connector 4 pieces
#29			
Remote 1 piece			

